



## Manual Softwareupdate SRT6125/6126/6130/6155/6355

Please note, that you also have to update Bootloader if necessary (you can find information about this in appendix).


1. Disconnect power cord of receiver
2. Connect Receiver and PC with Nullmodemcable
3. Start Software SERIALTRAN38 on PC
4. Press and hold **Channel-Down-Button** on housing of box and plug in power cord of box
5. Receiver starts in Update-Mode via serial connector
6. Press **PC to Box** Button in software



7. Choose software for upload on box



8. Choose options, which you want to update to box. It is recommended that you select preinstalled settings (all options).



9. Click on **Transfer** to start uploadprocess from PC to box




**Attention:** Do not break powerconnection while uploading. This could damage your box.

10. The process is finished, when box restarts automatically.


## Appendix:

Maybe it's necessary that you have to update Bootloader before you want to update software. This update must be done before you want to update software. Follow the steps:

1. Connect box to PC as described above and start SERIALTRAN38.
2. Load Bootloader to SERIALTRAN38. For that you have to change filetype to URT typ and choose the Bootloader.



3. Start Updateprocess by pressing **Transfer** Button



After the update of Bootloaders you can go on with updating software of box (as described above).